

Finding Your Ring Size

If You Have a Ring

Step 1:

Choose a ring that fits comfortably on the intended finger.

Step 2:


1. Place the ring on a ruler or caliper.
2. Measure the distance across the inside of the ring from one inner edge to the other.

Step 3:

Measure the distance from the center between the inner edges of your Ring.

Inner diameter measurement

$$2 \text{ cm} = 20 \text{ mm}$$



You now have the inner diameter of your ring, use the following chart to determine your ring size.

Inner Diameter	India Standard Size
16.3 mm	11
16.5 mm	12
16.9 mm	13
17.3 mm	14
17.5 mm	15
17.9 mm	16
18.1 mm	17
18.5 mm	18
18.7 mm	19
19.2 mm	20
19.4 mm	21
19.8 mm	22
20.0 mm	23
20.4 mm	24
20.6 mm	25

KYNA